

PUREAIRO

DUAL X

PART LIST



NO.	NAME	QUANTITY
1	Humidity sensor	1
2	Sensor bracket	1
3	Evaporator	1
4	Condenser	1
5	upper cover foam	1
6	Operation panel	1
7	Button board	1
8	Wind deflector	1
9	Fan	1
10	Motor bracket	1
11	Handle component	1
12	Back cover	1
13	Air outlet plastic parts	1
14	Condensation cover	1
15	Low pressure pipe	1
16	High pressure pipe	1
17	Water tray	1
18	compressor	1
19	Inlet panel	1
20	m6 screw	1
21	case	1
22	Step screw	1
23	Water pump components	1
24	8-inch wheels	4
25	Axle bracket	4
26	Chassis	1
27	Motor	1
28	Electric control box components	1
29	Fan capacitor	1
30	Compressor capacitor	1
31	Motherboard	1
32	Switch	1
33	power plug	1
34	Trip switch	1
35	Electric control cover	1

